



ADAPTABLE HOSE END SPRAYER

Model# 405-HE

## OPERATION AND SERVICE INSTRUCTIONS

**Warning:** This sprayer is designed to spray chemicals that may be harmful and could cause serious personal injury if inhaled or brought into contact with the user. Failure to read and follow Operation and Service Instructions before use and/or misuse of this product could result in product failure resulting in severe injuries.

- **ALWAYS** water test sprayer before each use.
- **ALWAYS** wear long sleeve shirts, long pants, goggles, gloves and durable shoes.
- **ALWAYS READ AND FOLLOW** manufacturers' recommended dilution rates for the chemical to be applied.
- **DO NOT** alter the sprayer.
- **DO NOT** spray flammable, caustic (i.e. acids, chlorines and bleach), corrosive, heated or self-heating solutions in the sprayer.
- **DO NOT** store liquids in the sprayer.

### Quick Connect hose connector is included

Anti-Siphon valve in swivel



Instant on/off Trigger

Can be used as traditional  
hose end sprayer



**Liquid dispensed through top hole only:**

- Stream for high places and tough rinse jobs
- Shower for delicate flora
- Flat fan for large areas
- Cone pattern for shrubs

## HOW TO USE

The Solo model 405-HE - the faster, easier to use, cleaner sprayer - keeps your hands chemical free. Three steps with no pouring, measuring or mixing:

1. Fill the included bottle with desired chemical concentrate and attach the Solo 405-HE to hose.
2. **The Solo 405-HE also adapts to most popular brands of chemical concentrate bottles.**
3. Adjust dial for desired per gallon of water concentration. Adjust sprayhead for desired spray pattern - stream, cone, shower, or flat fan.
4. Point, squeeze, and hold trigger. For best results, spray with a sweeping motion.

### LIQUID MEASUREMENTS

1 tablespoon (tbs) = 3 teaspoons (tsp)

2 tablespoons = 1 fluid oz. (fl. oz.)

1 cup = 16 tsp or 8 fl. oz.

1 pint = 16 fl. oz. (or 2 cups)

1 quart = 32 fl. oz. (or 2 pints)

## CLEANING INSTRUCTIONS

A properly cleaned sprayer will give you many years of use. You must clean the sprayer after each use.

Follow these instructions no matter how you adapt the sprayer for use:

1. Properly store any unused chemical concentrate or solutions in the original bottle or other suitable container.
2. Fill the tank with water and attach to the sprayer cap.
3. Put the dial on all the settings you used and thoroughly flush each setting.

### WARRANTY

**Solo** warrants to the original purchaser only that this product will continue to function as intended if used in accordance with the Operation and Service Instructions (UNDER NORMAL CONSUMER USE) for a period of 1 year from the date of purchase. If the product does not function as intended, DO NOT RETURN IT TO THE STORE - call the Solo Technical Services at 1-800-765-6462, 9:00 AM - 5:00 PM, EST. Please have the sprayer model number and purchase receipt available. Solo will, at our option, repair or replace any non-functioning part without charge, but SHIPPING AND HANDLING CHARGES WILL APPLY. Solo shall have the option of requiring the return of the non-functioning product with proof of purchase to establish a claim under the warranty. The warranty does not apply to damage resulting from accident, misuse, neglect, alterations, operation not in accordance with the instructions, commercial use or normal wear and tear.

ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR CONSUMER USE, ARE LIMITED TO THE DURATION AS SPECIFIED ABOVE. SOLO'S LIABILITY IS LIMITED SOLELY TO THE REPAIR OR REPLACEMENT OF THE NON-FUNCTIONING PRODUCT OR PART. SOLO EXCLUDES LIABILITY UNDER THIS WARRANTY FOR ANY AND ALL INCIDENTAL AND CONSEQUENTIAL DAMAGE.

### CUSTOMER SERVICE COMMITMENT FROM SOLO'S SERVICE DEPARTMENT

Solo is committed to your satisfaction and is continuing its efforts to earn your future business.

Please visit us online at [www.us.solo.global](http://www.us.solo.global).